


Braukmann DR300


Installation Instructions • Instrucciones de instalación • Instructions de montage
Installasjoninstruksjon • Monteringsvejledningen • Einbauanleitung


Components • Components • Pièces • Komponenter • Komponenter • Komponenten

- ① = Pilot valve
Válvula piloto
Vanne pilote
Pilotventil
Pilotventil
Pilotventil
- ② = Filter insert
Inserto de filtro
Garniture de filtration
Filterinnsats
Filterindsats
Filtereinsatz
- ③ = Manual ball valve
Válvula de bola manual
Clapet à bille
Manuell kuleventil
Manuel kugleventil
Handkugelhahn
- ④ = Control valve
Válvula de control
Valve de régulation
Reguleringsventil
Styreventil
Pilotgesteuerte Regelventile




Installation • Instalación • Installation • Installasjon • Installation • Installation





Closure pace adjustment • Ajuste del ritmo de cierre • Réglage de la vitesse de fermeture
• Justering av stengehastigheten • Lukkerhastighedsjustering • Verschlusszeitanpassung



Manufactured for
and on behalf of
Pittway Sàrl, Z.A., La Pièce 4,
1180 Rolle, Switzerland
by its authorised representative
Ademco 1 GmbH

For more information
homecomfort.resideo.com/europe

Ademco 1 GmbH, Hardhofweg 40,
74821 MOSBACH, GERMANY

Phone: +49 6261 810
Fax: +49 6261 81309